EVERC

Z-GRIP'GLAZE' OPTE

Z-GRIP GLAZE® OPTEX® Putty is a two-part, flowable, polyester finishing putty ideally suited for filling and skim coating body work, pinholes, grind marks, low spots, and other surface imperfections with patented OPTEX® color-changing technology. Can also be used to fill minor body damage up to 1/8" (3 mm) in depth.

- Color-changing technology
- Superior Adhesion to Galvanized Steel and Aluminum
- Tack Free
- No shrinkage



Available in: 30 ounce Pumptainer

evercoat.com

Z-GRIP® GLAZE® OPTEX® Putty Technical Data Sheet

100567: 30 Ounce Pumptainer 6 units/case

_	T	
Description	Z-GRIP GLAZE® OPTEX® Putty is a two-part, flowable, polyester finishing putty ideally suited for filling and skim coating body work, pinholes, grind marks, low spots, and other surface imperfections with patented OPTEX® color-changing technology. Can also be used to fill minor body damage up to 1/8" (3 mm) in depth.	
Approved Substrates	Approved substrates include: Sanded Body Filler, Steel, Galvanized Steel, Aluminum, Fiberglass, Stainless Steel, Most Rigid to Semi-Rigid Plastics, Sanded OEM Paint, Fiberglass	
	NOTE: For flexible plastics, use POLY-FLEX™ Flexible Glazing Putty.	
Preparation	 Clean and degrease the entire panel to be repaired with soap and water, followed by a mild cleaning solvent. Thoroughly dry the surface before repairing. Use 80-180 grit to remove or scuff the paint and featheredge. 	
Mixing +	 Place the desired amount of material on a clean, non-fibrous surface. Knead the cream hardener before use. Measure hardener 2% by weight (add a ribbon of cream hardener from edge to edge across the center of a 4" (10 cm) diameter puddle. Puddles larger than 4" in diameter will require additional hardener. Mix thoroughly until uniform color is achieved. Approximate setting time is 4 - 5 minutes @ 72°F (22°C) 	
Application	 Spread a thin layer of mixed material over surface using firm pressure. Apply additional layers to build material slightly higher than the surface to allow for sanding to desired contour The repair will gradually change color from pink to light blue-gray indicating that the repair is ready to sand. NOTE: Do not apply over new or uncured coatings. Avoid thick heavy applications. 	
Finishing	Sand to contour with 180 grit sandpaper. Final sand with 180 grit followed by 220-320 grit if desired	
Topcoat	• Apply 2K polyester, 2K urethane, 2K epoxy, or 1K primer to manufacturer's recommendations.	
	Appearance	Pink Thixotropic Liquid
Technical	VOC	Refer to Section 9 of the Safety Data Sheet
	Relative Density	Refer to Section 9 of the Safety Data Sheet
	Working Time	4-5 min.
	Sand Time	15-18 min.
	Max Recommended Thickness (sanded) 1/8 inch (3mm)
	NOTE: Properties are typical values and should not be considered as sales specifications. Physical testing performed @ ~72°F (22°C) / 75% RH unless otherwise noted.	
Safety	Read all directions and warnings prior to using Evercoat® products. Safety Data Sheets can be found online at evercoat.com. Note: Never return mixed filler to can. Keep can closed and store in a cool dry place. USE WITH EVERCOAT® CREAM HARDENER ONLY!	

